Getting Started With Your SHARP PERSONAL COMPUTER

THANK YOU FOR PURCHASING THE SHARP PERSONAL COMPUTER. YOU WILL ENJOY COMFORTABLE COMPUTING. BUT BEFORE STARTING TO USE YOUR COMPUTER, FOLLOW THE INSTRUCTIONS BELOW.

1 Open the carton box and check that the following items are included:

Power Cord



AC Adapter



Battery Pack



Modem Cable



Cores for IEEE 1394 Cable and LAN Cable



Recovery CD-ROM Pack



Windows XP Quick Start Guide



Operation Manual

* Carefully inspect each component to make sure nothing is missing or damaged. If any of these items is missing or damaged, notify your dealer immediately. Be sure to save the shipping materials and carton in case you need to ship or store the computer in the future.

* Attach a core to your LAN or IEEE1394 cable to insure compliance with requirements of EMC regulations for computing equipment.

* Some brochures or supplements may be contained other than the above.

2 Install the battery pack included with your computer.

1. Slide the battery lock lever to the left.



Battery Lock Lever

2. Install the battery into the computer.



3. Push the battery pack into the computer until you hear the clicking sound.



Go to the next page

4. Slide the battery lock lever to the right to lock the battery.



5. Turn over the computer and go to the next section.

3 Connect the AC adapter to the computer.



4 Open the display cover and set it to a comfortable viewing position.



5 Press the power button.



6 Remove the CD drive protection sheet.



Press the eject button to draw out the tray; then, remove the sheet.

7 Setup Windows operating system by following the instructions on the screen.

1. Click *Next* on Welcome to Microsoft Windows dialog box.



2. Select your location, language and keyboard; then, click *Next*.



3. Accept the license agreement; then, click *Next*.

4. Name your computer if you will be connecting to a LAN; then click *Next*. If you want to skip, click *Skip*.



5. Click *Skip* on An Internet Connection could not be chosen dialog box. You will be able to set up your internet connection once you have completed Windows setup.



6. Select *No.....* and click *Next*. You can register with Microsoft later.

7. Enter a user name in the box Your Name; then click *Next*. If you wish to add additional users, we recommend doing this after completing setup.



Go to the next page

8. Click *Finish* to complete the Windows setup.



After a few minutes delay, Windows XP will start. Double-click the time appearing at the bottom right of your screen, and set the correct time and date.

Now you are ready to use your computer. Enjoy the comfortable computing with SHARP PC-GP Series.

SUPPORT INFORMATION

PC Hardware Repair Line - 0870 901 3000

(Calls charged at BT national rate)

If you think that there is a problem with your PC hardware (e.g. the tray on the CD-ROM won't open or the PC won't switch on), you should call the Hardware Repair Line.
To use this line, your equipment must still be covered by the manufacturer's warranty or by a Mastercare Coverplan/PC Performance service agreement.

You will be asked for your till receipt number or service agreement reference number when you call, as proof of your entitlement to service. Please have this to hand. You will also need to have access to your PC when you call.

The Hardware Repair Line is only for customers who have bought their PC from PC World, Dixons or Currys.